

Xerox® Product Compatibility

macOS® Monterey

Xerox offers a wide variety of print drivers for the newest operating system from Apple — macOS® Monterey. The following table lists various Xerox® Office and Light Production products and information regarding the Xerox® Driver compatibility and availability. The table refers to a compatibility level for each product. It will be updated periodically as Xerox releases new macOS® Monterey-compatible device drivers.

Note: Support is provided for the current release of macOS® Monterey 12.0 and the preceding two versions of macOS (11.x and 10.15.x) with our latest driver.

To access drivers for your products, visit www.xerox.com/drivers, enter the name of your product, and select the Drivers and Downloads link from the resulting page.

ADDITIONAL RESOURCES

For more information about macOS® Monterey, go to <https://www.apple.com/macOS/monterey-preview>.

COMPATIBILITY LEVELS

COMPATIBILITY LEVEL	DESCRIPTION
1	Drivers for macOS® Monterey are available and can be downloaded from www.xerox.com/drivers .
2	This product does not have support for macOS® Monterey.
3	Delivery of updated drivers for macOS® Monterey is currently being evaluated for this product. Please continue to visit www.xerox.com/drivers for updates regarding our driver delivery plans.
4	Drivers developed for previous Apple OS versions may be compatible. See Additional Information section for your specific device.
5	To locate drivers for Fiery® Digital Print Servers or other Digital Front End, please visit www.support.xerox.com . Choose your device type and select the appropriate Digital Front End from the filters section. Additional drivers may also be available for download from the EFI® Download Center at www.efi.com/support-and-downloads/download-center

If your desired product does not indicate a print driver provided by Xerox, go to <https://www.support.xerox.com/en-us/article/en/2120800> for more information on utilizing macOS native capability to print using AirPrint™.

PRODUCT	COMPATIBILITY LEVEL	ADDITIONAL INFORMATION
Xerox® Printers and Multifunction Printers		
Xerox® AltaLink® B8045/B8055/B8065/B8075/B8090	1	
Xerox® AltaLink® C8030/C8035/C8045/C8055/C8070	1	
Xerox® AltaLink® B8145/B8155/B8170 Multifunction Printer	1	
Xerox® AltaLink® C8130/C8135/C8145/C8155/C8170 Color Multifunction Printer	1	
EFI® Fiery® Controller-Xerox® EX-c C8100 Print Server	5	
EFI® Fiery® Controller-Xerox® EX-c C8000 Print Server	5	
Xerox® B210	1	
Xerox® B205	1	
Xerox® B215	1	
Xerox® B225 Multifunction Printer	1	
Xerox® B230 Printer	1	
Xerox® B235 Multifunction Printer	1	

Xerox® Product Compatibility

macOS® Monterey

Xerox® B305 Multifunction Printer	<u>1</u>	
Xerox® B310 Printer	<u>1</u>	
Xerox® B315 Multifunction Printer	<u>1</u>	
Xerox® B1022 Multifunction Printer	<u>1</u>	
Xerox® B1025 Multifunction Printer	<u>1</u>	
Xerox® C230 Color Printer	<u>1</u>	
Xerox® C235 Color Multifunction Printer	<u>1</u>	
Xerox® ColorQube® 8570 Color Printer	<u>2</u>	
Xerox® ColorQube® 8580 Color Printer	<u>1</u>	
Xerox® ColorQube® 8700 Color Multifunction Printer	<u>1</u>	
Xerox® ColorQube® 8870 Color Printer	<u>2</u>	
Xerox® ColorQube® 8880 Color Printer	<u>1</u>	
Xerox® ColorQube® 8900 Color Multifunction Printer	<u>1</u>	
Xerox® ColorQube® 9201/9202/9203 Color Multifunction Printer	<u>2</u>	
Xerox® ColorQube® 9301/9302/9303 Color Multifunction Printer	<u>1</u>	
Xerox® EC8036 Color Multifunction Printer	<u>1</u>	
Xerox® EC8056 Color Multifunction Printer	<u>1</u>	
Xerox® Phaser® 3010 Printer	<u>2</u>	
Xerox® Phaser® 3020 Printer	<u>1</u>	
Xerox® Phaser® 3040 Printer	<u>2</u>	
Xerox® Phaser® 3052 Printer	<u>1</u>	
Xerox® Phaser® 3250 Printer	<u>2</u>	
Xerox® Phaser® 3260 Printer	<u>1</u>	
Xerox® Phaser® 3320 Printer	<u>2</u>	
Xerox® Phaser® 3330 Printer	<u>1</u>	
Xerox® Phaser® 3610 Printer	<u>1</u>	
Xerox® Phaser® 3635 Multifunction Printer	<u>2</u>	
Xerox® Phaser® 4622 Printer	<u>1</u>	
Xerox® Phaser® 6000 Color Printer	<u>2</u>	
Xerox® Phaser® 6010 Color Printer	<u>2</u>	
Xerox® Phaser® 6020 Color Printer	<u>1</u>	See https://www.support.xerox.com/en-us/product/phaser-6020/downloads for latest drivers.
Xerox® Phaser® 6022 Color Printer	<u>1</u>	See https://www.support.xerox.com/en-us/product/phaser-6022/downloads for latest drivers.
Xerox® Phaser® 6500 Color Printer	<u>2</u>	
Xerox® Phaser® 6510 Color Printer	<u>1</u>	
Xerox® Phaser® 6600 Color Printer	<u>1</u>	
Xerox® Phaser® 6700 Color Printer	<u>1</u>	
Xerox® Phaser® 7100 Color Printer	<u>1</u>	
Xerox® Phaser® 7500 Color Printer	<u>1</u>	
Xerox® Phaser® 7800 Color Printer	<u>1</u>	
Xerox® VersaLink® B400 Printer	<u>1</u>	
Xerox® VersaLink® B405 Multifunction Printer	<u>1</u>	

Xerox® Product Compatibility

macOS® Monterey

Xerox® VersaLink® C400 Color Printer	<u>1</u>	
Xerox® VersaLink® C405 Color Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C500 Color Printer	<u>1</u>	
Xerox® VersaLink® C505 Color Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C600 Color Printer	<u>1</u>	
Xerox® VersaLink® C605 Color Multifunction Printer	<u>1</u>	
Xerox® VersaLink® B7025/B7030/B7035 Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C7000 Color Printer	<u>1</u>	
Xerox® VersaLink® C7020/C7025/C7030 Color Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C8000/C9000 Color Printer	<u>1</u>	
Xerox® WorkCentre® Pro C2128/C2636/C3545 Color Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 3025 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 3045 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 3210/3220 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 3215 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 3225 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 3315/3325 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 3335/3345 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 3615 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 3655 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 3655i Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 4250 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 4260 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 4265 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 5135/5150 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 5222/5225/5230 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 5325/5330/5335 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 5632/5638/5645/5655/5665/5675/5687 Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 5735/5740/5745/5755/5765/5775/5790 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 5845/5855/5865/5875/5890 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 5865i/5875i/5890i Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 5945/5955 Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 5945i/5955i Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 6015 Color Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 6025 Color Multifunction Printer	<u>1</u>	See https://www.support.xerox.com/en-us/product/workcentre-6025/downloads for latest drivers.
Xerox® WorkCentre® 6027 Color Multifunction Printer	<u>1</u>	See https://www.support.xerox.com/en-us/product/workcentre-6027/downloads for latest drivers.
Xerox® WorkCentre® 6400 Color Multifunction Printer	<u>1</u>	

Xerox® Product Compatibility

macOS® Monterey

Xerox® WorkCentre® 6505 Color Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 6515 Color Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 6605 Color Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 6655 Color Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 6655i Color Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 7120/7125 Color Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 7220/7225 Color Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 7220i/7225i Color Multifunction Printer	<u>1</u>	
Xerox® WorkCentre® 7328/7335/7345/7346 Color Multifunction Printer Built-in Controller	<u>2</u>	
EFI® Fiery® Controller	<u>5</u>	
Xerox® WorkCentre® 7425/7428/7435 Color Multifunction Printer Built-in Controller	<u>2</u>	
EFI® Fiery® Controller	<u>5</u>	
Xerox® WorkCentre® 7525/7530/7535/7545/7556 Color Multifunction Printer Built-in Controller	<u>1</u>	
EFI® Fiery® Controller	<u>5</u>	
Xerox® WorkCentre® 7655/7665/7675 Color Multifunction Printer	<u>2</u>	
Xerox® WorkCentre® 7755/7765/7775 Color Multifunction Printer Built-in Controller	<u>2</u>	
EFI® Fiery® Controller	<u>5</u>	
Xerox® WorkCentre® 7830/7835/7845/7855	<u>1</u>	
EFI® Fiery® Network Server	<u>5</u>	
Xerox® WorkCentre® 7830i/7835i/7845i/7855i	<u>1</u>	
EFI® Fiery® Network Server	<u>5</u>	
Xerox® WorkCentre® 7970	<u>1</u>	
Xerox® WorkCentre® 7970i	<u>1</u>	
EFI® Fiery® Network Server	<u>5</u>	
Xerox® WorkCentre® EC7836/EC7856	<u>1</u>	
ENTRY PRODUCTION COLOR PRODUCTS		
Xerox® Color C75 Press Xerox® FreeFlow® Print Server	<u>1</u>	
Integrated Fiery® Color Server	<u>5</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® Color J75 Press Xerox® FreeFlow® Print Server	<u>1</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® Color C60/C70 Printer Built-in Controller	<u>1</u>	
Xerox® FreeFlow® Print Server	<u>1</u>	
Integrated Fiery® EX-i Color Server	<u>5</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	

Xerox® Product Compatibility

macOS® Monterey

Xerox® Color EC70 Printer Built-in Controller	<u>1</u>	Use driver for Xerox® Color C60/C70 Printer Integrated Color Server
Xerox® EX-i Print Server for EC70	<u>5</u>	
Xerox® Color 550/560 Printer Built-in Controller	<u>2</u>	
Xerox® FreeFlow® Print Server	<u>2</u>	
Integrated Fiery® Color Server	<u>5</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® Color 560/570 Printer Built-in Controller	<u>2</u>	
Xerox® FreeFlow® Print Server	<u>2</u>	
Integrated Fiery® EX-i Color Server	<u>5</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® DocuColor® 242/252/260 Xerox® FreeFlow® DXP260	<u>2</u>	
Built-in Fiery® Controller	<u>5</u>	
EFI® Fiery® EX260	<u>5</u>	
Xerox® PrimeLink® C9065/C9070 Built-in Controller	<u>1</u>	
Xerox® EX C9065/C9070 Print Server (powered by Fiery®)	<u>5</u>	
Xerox® EX-i C9065/C9070 Print Server (powered by Fiery®)	<u>5</u>	
Xerox® EX-c C9065/C9070 Print Server (powered by Fiery®)	<u>5</u>	
LIGHT PRODUCTION MONOCHROME PRODUCTS		
Xerox® D95/D95A/D110/D125 Copier/Printer and Printer Xerox® FreeFlow® Print Server	<u>1</u>	
Built-in Controller	<u>1</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® ED95A/ED125 Copier/Printer Built-in Controller	<u>1</u>	Use driver for Xerox® D95/D110/D125 Copier/Printer built-in controller
Xerox® EXII Print Server for ED95A/ED125	<u>5</u>	
Xerox® D136 Copier/Printer and Printer Xerox® FreeFlow® Print Server	<u>2</u>	
Built-in Controller	<u>1</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® PrimeLink® B9100/B9110/B9125/B9136 Copier/Printer Integrated Server (supported)	<u>1</u>	
EX Print Server	<u>5</u>	
Xerox® FreeFlow® 4112/4127 Enterprise Printing System Xerox® FreeFlow® Print Server	<u>2</u>	

Xerox® Product Compatibility

macOS® Monterey

XEROX SUPPORT CONTACT INFORMATION

For additional information or clarification for any of the product information presented in this document, please contact your local Xerox Customer Support Center, Xerox Customer Support at 1-800-821-2797 (U.S.), TTY 1-800-855-2880, or visit <http://www.support.xerox.com>.