



BPA Transmission Facilities

- BPA Transmission Lines
- BPA Substations

0 25 50 75 100 Miles

Compass rose showing North (N), South (S), East (E), and West (W).

