

Takeoff: A'SS Lakeland
Loral

Dropsonde Scientist

Flight ID 20210818H1

Storm Grace

Mission ID 1407A

Dropsonde Scientists

Sellwood

AVAPS Operators

Underswood

The Lead Project Scientist (LPS) on the P3 is responsible for determining the distribution patterns for dropwindsonde releases. Predetermined desired data collection patterns are illustrated on the flight patterns. However, these patterns are often altered because of clearance problems, etc. Operational procedures are contained in the operator's manual. On the G-IV the sole HRD person is designated the LPS. The following list contains more general supplementary procedures to be followed. (Check off or initial.)

Preflight

- 1. Determine the status of the AVAPS and workstation. Report results to the LPS.
- 2. Confirm the mission and pattern selection with the LPS and assure that enough dropsondes are on board the aircraft.
- 3. Modify the flight pattern or drop locations if requested by AOC to accommodate changes in storm location or closeness to land.
- 4. Complete the appropriate preflight set-up and checklists.

In-Flight

- 1. Operate the system as specified in the operator's manual.
- 2. Ensure the AOC flight director is aware of upcoming drops.
- 3. Ensure the AVAPS operator has determined that the dropsonde is (or is not) transmitting a good signal. Recommend if a backup dropsonde should be launched in case of failure.
- 4. Report the transmission of each drop and fill in the Dropwindsonde Scientist Log.

Post flight

- 1. Complete Dropwindsonde Scientist Log.
- 2. Download all raw and processed AVAPS files to thumbdrive
- 3. Brief the LPS on equipment status and turn in completed forms and thumbdrive.
- 4. Debrief at the base of operations.
- 5. Determine the status of future missions and notify Field Program Director as to where you can be contacted.

Storm Grace
Mission ID | 407A

NOAA P-3 GPS Dropwindsonde Scientist Log (revised March 2019)

Flight ID 2021081841 Dropsonde Scientist Sellwood AVAPS Operator Underwood
(exp. 0213A) Dropsonde Scientist AVAPS Operator

Drop #	Sonde ID	Time UTC	Lat (°N/S)	Long (°E/W)	Sfc Pressure (mb)	Wind closest to Dir/Spd (deg/kts)	SST (°C)	EyeEyewall, Rainband/etc,	Ob #
1	203430202090	2127	21.10	-85.05	1012	085/151	12	50	1
Comments	A/B/T combo T/T NW end 243.25								
2	203431514	2136	20.65	-84.27	1059	060/43	10		2
Comments	Midpoint inbound (early) removed RT at top								
3	203451324	2145	20.19	-84.47	1003	060/58	10		3
Comments	Comment								
4	203451325	2154	20.14	-84.48	1003	060/58	10		4
Comments	Comment								
5	203451326	2201	19.87	-83.88	1004	200/28	10		5
Comments	Comment								
6	203451326	2208	18.88	-83.64	1007	180/25	10		6
Comments	Midpoint end 232.50								
7	203450235	2224	18.21	-82.85	1010	165/25	10		7
Comments	Endpoint 55								
8	203450003	2241	19.35	-83.39	1011	105/53	10		8
Comments	Endpoint E								
9	203451520	2257	19.86	-83.55	1008	105/49	10		9
Comments	Midpoint inbound								
10	203451524	2305	19.86	-84.04	1003	103/47	10		10
Comments	Endpoint inbound								

1
2
3
4
5
6
7
8
9
10

NOAA P-3 GPS Dropwindsonde Scientist Log (revised March 2019)

AVAPS Operator
AVAPS Operator
Page#

NOAA P-3 GPS Dropwindsonde Scientist Log (revised March 2019)

Dropsonde Scientist

Flight ID
(ex: 001130)

Storm Mission

AVAPS Operator