

# Premium Wall & Wood

## Interior Latex Primer

B28W08111 White


**SHERWIN  
WILLIAMS.**

### CHARACTERISTICS

#### Premium Wall & Wood Interior Latex Primer:

- Assures uniform color and gloss of topcoats on walls, doors, and trim
- Assures consistent and maximum sheen of enamel topcoats on surfaces of varying porosity
- Quick drying
- Fast sanding
- Excellent coverage
- Quality sealer under wallcovering

**Sanding:** Premium Wall & Wood Primer is designed to sand quickly, to a powder, in 2 hours. Use medium to fine sandpaper and lightly sand. Little effort is required for a smooth finish.

#### For use on these surfaces:

- Wood
- Drywall
- Plaster
- Plywood
- Primed Metal
- Previously painted surfaces

**Color:** White  
For best color development, use the recommended "p"-shade primer. Check color before use.

**Coverage:** 400 sq. ft. per gallon  
@ 4 mils wet; 1.5 mils dry

**Drying Time, @ 77° F, 50% RH:**

**Touch:** 30 minutes

**Sand:** 2 hours

**Recoat:** 2 hours

Drying and recoat times are temperature, humidity, and film thickness dependent.

**Finish:** 0-5 units @ 85°

**Tinting with CCE Only:** For best topcoat color development, use a recommended "P"-shade primer. If desired, up to 4 ounces per gallon of ColorCast Ecotoners can be used to approximate the topcoat color. Check color before use.

#### White B28W08111

(may vary by color)

#### V.O.C. (less exempt solvents):

less than 50 grams per litre; 0.42 lbs. per gallon  
As per 40 CFR 59.406

**Volume Solids:** 38 ±2%

**Weight Solids:** 54 ±2%

**Weight per Gallon:** 11.20 lbs

**Flash Point:** N.A.

**Vehicle Type:** Vinyl Acrylic Latex

**Shelf Life:** 36 months, unopened

**WVP Perms (US):** 46.36 grains/(hr ft<sup>2</sup> in Hg)

### COMPLIANCE

As of 8/1/2023, Complies with:

<b>OTC</b>	Yes
<b>OTC Phase II</b>	Yes
<b>S.C.A.Q.M.D.</b>	Yes
<b>CARB</b>	Yes
<b>CARB SCM 2007</b>	Yes
<b>CARB SCM 2020</b>	Yes
<b>Canada</b>	Yes
<b>LEED® v4 &amp; v4.1 Emissions</b>	No
<b>LEED® v4 &amp; v4.1 V.O.C.</b>	Yes
<b>EPD-NSF® Certified</b>	No
<b>MIR-Manufacturer Inventory</b>	No
<b>MPI®</b>	No

### APPLICATION

Apply at temperatures above 50°F.

No reduction necessary.

#### Brush:

Use a nylon-polyester brush.

#### Roller:

Use a 1/4-3/4 inch nap synthetic cover.

For specific brushes and rollers, please refer to our Brush and Roller Guide on [sherwin-williams.com](http://sherwin-williams.com)

#### Spray - Airless:

Pressure 2000 p.s.i.  
Tip .017-.021 inch

**HVLP:** Cap #3-4  
Reduction as needed up to 10%

### APPLICATION TIPS

When spot priming on some surfaces, a non-uniform appearance of the final coat may result, due to differences in holdout between primed and unprimed areas. To avoid this, prime the entire surface rather than spot priming.

For optimal performance, this primer must be topcoated with a latex, alkyd-oil, water-based epoxy, or solvent based epoxy coating on architectural applications.

### SPECIFICATIONS

#### Drywall:

1 coat Premium Wall & Wood Interior Primer  
2 coats appropriate topcoat

#### Wood:

1 coat Premium Wall & Wood Interior Primer  
2 coats appropriate topcoat

# Premium Wall & Wood

## Interior Latex Primer

### SURFACE PREPARATION

**WARNING!** If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to [www.epa.gov/lead](http://www.epa.gov/lead).

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Sand Glossy surfaces dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer-sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

#### **Caulking:**

Fill gaps between walls, ceiling, crown moldings, and other trim with the appropriate caulk after priming the surface.

#### **Drywall:**

Fill cracks and nail holes with patching paste-spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

#### **Masonry, Concrete, Cement, Block:**

All new surfaces must be cured according to the supplier's recommendations-usually about 30 days. Remove all form release and curing agents. Masonry surfaces must be dry before priming. Moisture content must be 15% or lower and the pH between 5 and 9.

If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.

Rough surfaces can be filled with Loxon Acrylic Block Surfacer to provide a smooth surface.

### SURFACE PREPARATION

#### **Mildew:**

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts clean water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with clean water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach-water solution.

#### **Plaster:**

Bare plaster must be cured, usually 30 days, and hard. If painting cannot wait, allow the surface to dry 7 days and prime with Loxon Concrete and Masonry Primer. Soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of clean water. Repeat until the surface is hard, rinse with clear water and allow to dry.

#### **Wood Hardboard:**

Sand bare wood to a fresh surface. Patch holes and imperfections with wood filler-putty and sand smooth. Remove sanding dust. When used as an enamel undercoater, Premium Wall & Wood Primer is designed to minimize wood grain raising.

On woods that present potential knot or tannin bleeding, such as redwood and cedar, use Multi-Purpose Latex Primer.

### CAUTIONS

For interior use only.

Protect from freezing.

Non-Photochemically reactive.

Before using, carefully read **CAUTIONS on label**.

**CRYSTALLINE SILICA** Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Adequate ventilation required when sanding or abrading the dried film. If adequate ventilation cannot be provided wear an approved particulate respirator (NIOSH approved). Follow respirator manufacturer's directions for respirator use. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **DELAYED EFFECTS FROM LONG TERM OVEREXPOSURE.** Abrading or sanding of the dry film may release crystalline silica which has been shown to cause lung damage and cancer under long term exposure. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**

HOTW 8/1/2023 B28W08111 20 39  
SP

### CLEANUP INFORMATION

Clean spills, splatters, hands and tools immediately after use with soap and clean warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.